



ECLIPSE

Calculating drawer box dimensions

Formula for calculating outside drawer length												
Slide length	*10"	12"	14"	15"	16"	18"	20"	21"	22"	24"	26"	28"
Outside drawer box length	*10"	12"	14"	15"	16"	18"	20"	21"	22"	24"	26"	28"
Drawer box length tolerance is +0/ -1/16"												
Formula for calculating inside drawer width												
For drawer side thickness	5/8"	16.00 mm	19/32"	15.00 mm	9/16"	14.00 mm	1/2"	13.00 mm				
Deduct from inside cabinet width	1-3/4"	44.45 mm	1-3/4"	44.45 mm	1-3/4"	44.45 mm	1-3/4"	44.45 mm				
Formula for calculating outside drawer width												
For drawer side thickness	5/8"	16.00 mm	19/32"	15.00 mm	9/16"	14.00 mm	1/2"	13.00 mm				
Deduct from inside cabinet width	1/2"	13.00 mm	9/16"	15.00 mm	5/8"	17.00 mm	3/4"	19.00 mm				

* Available for 3132EC only

Accuride®

www accuride.com • 12311 Shoemaker Avenue • Santa Fe Springs, CA 90670 • (562) 903-0200